



# ADDENDA

**ANSI/ASHRAE Addendum co to  
ANSI/ASHRAE Standard 135-2020**



# A Data Communication Protocol for Building Automation and Control Networks

Approved by ASHRAE and by the American National Standards Institute on September 30, 2024.

This addendum was approved by a Standing Standard Project Committee (SSPC) for which the Standards Committee has established a documented program for regular publication of addenda or revisions, including procedures for timely, documented, consensus action on requests for change to any part of the standard. Instructions for how to submit a change can be found on the ASHRAE® website ([www.ashrae.org/continuous-maintenance](http://www.ashrae.org/continuous-maintenance)).

The latest edition of an ASHRAE Standard may be purchased on the ASHRAE website ([www.ashrae.org](http://www.ashrae.org)) or from ASHRAE Customer Service, 180 Technology Parkway, Peachtree Corners, GA 30092. E-mail: [orders@ashrae.org](mailto:orders@ashrae.org). Fax: 678-539-2129. Telephone: 404-636-8400 (worldwide), or toll free 1-800-527-4723 (for orders in US and Canada). For reprint permission, go to [www.ashrae.org/permissions](http://www.ashrae.org/permissions).

© 2024 ASHRAE

ISSN 1041-2336



**ASHRAE Standing Standard Project Committee 135**

**Cognizant TC: 1.4, Control Theory and Application**

**SPLS Liaison: Paul Lindahl**

Coleman L. Brumley, Jr.*, <i>Chair</i>	David Fisher	David Robin*
Scott Ziegenfus, <i>Vice Chair</i>	Alexander Gurciullo*	Frank Schubert
Salvatore Cataldi*, <i>Secretary</i>	Bernhard Isler	Steven C. Sill*
Nate Benes*	Thomas Kurowski*	Marcelo Richter da Silva
Steven T. Bushby*	Shahid Naem	Ted Sunderland
James F. Butler	Frank Victor Neher*	Lori Tribble
Tyler Cove	Michael Osborne*	Grant N. Wichenko*
Brandon Michael DuPrey*	Scott Reed	Christoph Zeller

\* Denotes members of voting status when the document was approved for publication

---

**ASHRAE STANDARDS COMMITTEE 2024–2025**

Douglas D. Fick, <i>Chair</i>	Satish N. Iyengar	Gwelen Paliaga
Adrienne G. Thomle, <i>Vice Chair</i>	Phillip A. Johnson	Karl L. Peterman
Hoy R. Bohanon, Jr.	Paul A. Lindahl, Jr.	Justin M. Prosser
Kelley P. Cramm	Julie Majurin	Christopher J. Seeton
Abdel K. Darwich	Lawrence C. Markel	Paolo M. Tronville
Drake H. Erbe	Margaret M. Mathison	Douglas K. Tucker
Patricia Graef	Kenneth A. Monroe	William F. Walter
William M. Healy	Daniel H. Nall	David P. Yuill
Jaap Hogeling	Philip J. Naughton	Susanna S. Hanson, <i>BOD ExO</i>
Jennifer A. Isenbeck	Kathleen Owen	Wade H. Conlan, <i>CO</i>

Ryan Shanley, *Senior Manager of Standards*

---

**SPECIAL NOTE**

This American National Standard (ANS) is a national voluntary consensus Standard developed under the auspices of ASHRAE. *Consensus* is defined by the American National Standards Institute (ANSI), of which ASHRAE is a member and which has approved this Standard as an ANS, as "substantial agreement reached by directly and materially affected interest categories. This signifies the concurrence of more than a simple majority, but not necessarily unanimity. Consensus requires that all views and objections be considered, and that an effort be made toward their resolution." Compliance with this Standard is voluntary until and unless a legal jurisdiction makes compliance mandatory through legislation.

ASHRAE obtains consensus through participation of its national and international members, associated societies, and public review.

ASHRAE Standards are prepared by a Project Committee appointed specifically for the purpose of writing the Standard. The Project Committee Chair and Vice-Chair must be members of ASHRAE; while other committee members may or may not be ASHRAE members, all must be technically qualified in the subject area of the Standard. Every effort is made to balance the concerned interests on all Project Committees.

The Senior Manager of Standards of ASHRAE should be contacted for

- interpretation of the contents of this Standard,
- participation in the next review of the Standard,
- offering constructive criticism for improving the Standard, or
- permission to reprint portions of the Standard.

**DISCLAIMER**

ASHRAE uses its best efforts to promulgate Standards and Guidelines for the benefit of the public in light of available information and accepted industry practices. However, ASHRAE does not guarantee, certify, or assure the safety or performance of any products, components, or systems tested, installed, or operated in accordance with ASHRAE's Standards or Guidelines or that any tests conducted under its Standards or Guidelines will be nonhazardous or free from risk.

**ASHRAE INDUSTRIAL ADVERTISING POLICY ON STANDARDS**

ASHRAE Standards and Guidelines are established to assist industry and the public by offering a uniform method of testing for rating purposes, by suggesting safe practices in designing and installing equipment, by providing proper definitions of this equipment, and by providing other information that may serve to guide the industry. The creation of ASHRAE Standards and Guidelines is determined by the need for them, and conformance to them is completely voluntary.

In referring to this Standard or Guideline and in marking of equipment and in advertising, no claim shall be made, either stated or implied, that the product has been approved by ASHRAE.

**[This foreword, the table of contents, the introduction, and the “rationales” on the following pages are not part of this standard. They are merely informative and do not contain requirements necessary for conformance to the standard.]**

## FOREWORD

*Addendum co is the result of change proposals made pursuant to the ASHRAE continuous maintenance procedures and of deliberations within Standing Standard Project Committee 135. The changes are summarized as follows:*

**135-2020co-1 Clarify Reliability-Evaluation, p. 3**

**135-2020co-2 Event and Fault Parameter Consistency, p. 5**

In the following document, language to be added to existing clauses of ANSI/ASHRAE 135-2020 is indicated through the use of *italics*, while deletions are indicated by ~~strike through~~. Where entirely new subclauses are proposed to be added, plain type is used throughout. Only this new and deleted text is open to comment at this time. All other material in this document is provided for context only and is not open for public review comment except as it relates to the proposed changes.

The use of placeholders like XX, YY, ZZ, X1, X2, NN, x, n, ? etc. should not be interpreted as literal values of the final published version. These placeholders will be assigned actual numbers/letters only after final publication approval of the addendum.

## 135-2020~~co~~-1 Clarify Reliability-Evaluation

### Rationale

Specify the expected actions when Out\_Of\_Service is TRUE and Reliability is written.

Move and clarify the reliability-evaluation language to improve the understanding of the different fault conditions.

[Change **Clause 12.1.8 Reliability**, p. 163]

### 12.1.8 Reliability

Several object types defined in this clause have a property called "Reliability" that indicates the existence of fault conditions for the object. Reliability-evaluation is the process of determining the value for this property. *See Clause 13.2.2.X. Reliability-evaluation is separate from, but used by, event reporting and may be supported by objects that do not support event reporting.*

~~The first stage of reliability evaluation is internal to the object and is completely defined by the device's vendor. The second stage, which is only found in certain object types, is the application of a fault algorithm. Faults detected in the first stage shall take precedence over faults detected in the second stage. See Clause 13.4 for fault algorithm definitions and see the object type definitions to determine the fault algorithm supported by any particular object type. The different values that the Reliability property can take on are described below. Note that not all values are applicable to all object types.~~

...

[Add **Clause 13.2.2.X**, p. 641]

### 13.2.2.X Reliability-Evaluation

Reliability-evaluation is the process of determining the value for the Reliability property. Reliability-evaluation is separate from, but used by, event reporting and may be supported by objects that do not support event reporting.

The first stage of reliability-evaluation is internal to the object. The first stage checks for internal faults such as configuration errors, hardware faults or communication failures. Except where required by an object type definition, the specific conditions checked for, the methods used, and the reliability values supported are defined by the device's vendor. Faults detected in the first stage shall take precedence over faults detected in the second stage.

The second stage, which is only found in certain object types, is the application of a standardized fault algorithm. The standard fault algorithms are defined in Clause 13.4. Each object type definition in Clause 12 indicates whether or not a standardized fault algorithm may be applied by objects of that type, and which standardized fault algorithms may be applied.

[Add **Clause 13.2.2.Y**, p. 641]

### 13.2.2.Y Simulating Events Using Out\_Of\_Service

The value of the object's Out\_Of\_Service property does not affect the event-state-detection process.

While Out\_Of\_Service is TRUE, writing to the object's monitored value can be used to simulate specific event states including values that would cause the application of an event algorithm or a fault algorithm. An application of a fault algorithm shall also result in a change to the value of the Reliability property.

While Out\_Of\_Service is TRUE, writing to the object's Reliability property can be used to simulate internal faults. See Clause 13.2.2.X. A successful write to the Reliability property shall cause the event state to be evaluated and block the object from updating the Reliability property. Writing the Out\_Of\_Service property to FALSE shall remove the block allowing the object to update the Reliability property.

It is a local matter what reliability values are supported when Out\_Of\_Service is TRUE. An unsuccessful attempt to write to the Reliability property shall return a Result(-) with 'Error Class' = PROPERTY and 'Error Code' = INVALID\_VALUE\_IN\_THIS\_STATE.

[Change **Clause 13.3.17 NONE Event Algorithm**, p. 673]

### 13.3.17 NONE Event Algorithm

*The NONE event algorithm is a placeholder for the case where no event algorithm is applied by the object. This placeholder is used in those objects that are able to indicate which event algorithm they apply. For example, an Event Enrollment object's Event\_Type property is set to NONE to indicate that it is not applying an event algorithm.*

~~This event algorithm has no parameters, no conditions, and does not indicate any transitions of event state.~~

~~The NONE algorithm is used when only fault detection is in use by an object.~~

[Change **Clause 13.4.1 NONE Fault Algorithm**, p. 676]

### 13.4.1 NONE Fault Algorithm

*The NONE fault algorithm is a placeholder for the case where no standardized fault algorithm is applied by the object in the second stage of reliability-evaluation. This placeholder is used in those objects that are able to indicate which standardized fault algorithm they apply. For example, an Event Enrollment object's Fault\_Type property is set to NONE to indicate that it is not applying a standardized fault algorithm.*

~~This fault algorithm has no parameters, no conditions, and does not indicate any transitions of reliability.~~

[Change **Clauses 12.10, 12.11, 12.21, 12.22, 12.24, 12.36, 12.38, 12.42, 12.45, 12.46, 12.47, 12.48, 12.56, 12.62, 12.63, 12.64**]

[object type] objects may optionally support intrinsic reporting to facilitate the reporting of fault conditions. [object type] objects that are capable of detecting faults, shall only perform the first stage of reliability-evaluation and shall not apply a standardized fault algorithm. [object type] objects that support intrinsic reporting shall ~~apply the NONE~~ not apply an event algorithm.

...

[Change **Table 12-15, Table 12-15.1, Table 12-15.2, Table 12-15.3**]

NONE	<del>none/a</del>	<del>none/a</del>
------	-------------------	-------------------

## 135-2020co-2 Event and Fault Parameter Consistency

### Rationale

Several event and fault algorithms have parameters that may be configured in conflict with each other. This may have different effects such as the algorithm being switched off, OFFNORMAL or even LIFESAFETY\_ALARM states not being detected, ambiguity in resulting event state, or infinite event state transition loops.

The CHANGE\_OF\_CHARACTERSTRING, CHANGE\_OF\_LIFE\_SAFETY, and the CHANGE\_OF\_STATE event algorithms have paralleling fault algorithms with which the offnormal values lists should be coordinated. Having a particular value in both an event parameter value list and in the fault parameter values list leads to the value in the event parameter is ignored, and only TO\_FAULT event transitions are indicated for that particular value.

The CHANGE\_OF\_LIFE\_SAFETY event algorithm, as currently specified, even goes into an infinite loop between OFFNORMAL and LIFESAFETY\_ALARM event state if a particular state value is present in both pAlarmValues and pLifeSafetyAlarmValues parameters.

The DOUBLE\_OUT\_OF\_RANGE, OUT\_OF\_RANGE, SIGNED\_OUT\_OF\_RANGE, UNSIGNED\_OUT\_OF\_RANGE, and UNSIGNED\_RANGE event algorithms all have a low limit and a high limit parameter. These limits, when configured with pLowLimit > pHighLimit, may cause the algorithm, for particular monitored values, to loop between HIGH\_LIMIT and LOW\_LIMIT event states.

The FLOATING\_LIMIT algorithm, when configured with negative values in pLowLimit or pHighLimit, may cause the algorithm, for particular monitored values, to continuously loop between HIGH\_LIMIT and LOW\_LIMIT event states.

The FAULT\_CHARACTERSTRING, FAULT\_LIFE\_SAFETY, and FAULT\_STATE algorithms pFaultValues parameter should not include a value that is also present in an event algorithm parameter of the object. Otherwise, this value is ever indicated as a FAULT event state transition only.

The FAULT\_OUT\_OF\_RANGE fault algorithm parameters, when configured to be pMinimumNormalValue > pMaximumNormalValue, may cause the algorithm, for particular monitored values, to continuously toggle between UNDER\_RANGE and OVER\_RANGE reliability.

Objects containing such conflicting event and fault parameters are taking a reliability status of CONFIGURATION\_ERROR. This inhibits execution of the event algorithm and the fault algorithm if present, on such conflicting configurations. Respective language is added to event and fault parameter properties describing the situations considered a conflicting configuration.

[Change **Clause 12.12.21**, Event Enrollment object type, p. 237]

### 12.12.21 Reliability

...

*The Reliability property shall take on a value of CONFIGURATION\_ERROR under these conditions:*

- *For the CHANGE\_OF\_CHARACTERSTRING event algorithm and FAULT\_CHARACTERSTRING fault algorithm, if a particular value is present in both the List\_Of\_Alarm\_Values parameter in the Event\_Parameters property and in the List\_Of\_Fault\_Values parameter in the Fault\_Parameters property, or*
- *for the CHANGE\_OF\_LIFE\_SAFETY event algorithm and FAULT\_LIFE\_SAFETY fault algorithm, if a particular value is present in more than one of the List\_Of\_Alarm\_Values parameter or the List\_Of\_Life\_Safety\_Alarm\_Values parameter in the Event\_Parameters property and the List\_Of\_Fault\_Values parameter in the Fault\_Parameters property, or*
- *for the CHANGE\_OF\_STATE event algorithm and the FAULT\_STATE fault algorithm, if a particular value is present in both the List\_Of\_Values parameter in the Event\_Parameters property and the List\_Of\_Fault\_Values parameter in the Fault\_Parameters property, or*
- *for the DOUBLE\_OUT\_OF\_RANGE, OUT\_OF\_RANGE, SIGNED\_OUT\_OF\_RANGE, UNSIGNED\_OUT\_OF\_RANGE, and UNSIGNED\_RANGE event algorithms, if the Low\_Limit parameter is greater than the High\_Limit parameter, or*

- *for the FLOATING\_LIMIT event algorithm, if the Low\_Diff\_Limit parameter or the High\_Diff\_Limit parameter or both have numerically negative values.*

[Change **Clause 12.37.8**, CharacterString Value object type, p. 417;  
Change **Clause 12.18.9**, Multi-state Input object type, p. 270;  
Change **Clause 12.20.8**, Multi-state Value object type, p. 283;  
Change **Clause 12.26.8**, Access Door object type, p. 328]

## **12.?.? Reliability**

...

*The Reliability property shall take on a value of CONFIGURATION\_ERROR if a particular value is present in both the Alarm\_Values property and in the Fault\_Values property.*

[Change **Clause 12.3.9**, Analog Output object type, p. 174;  
Change **Clause 12.23.9**, Pulse Converter object type, p. 303]

## **12.?.9 Reliability**

...

*The Reliability property shall take on a value of CONFIGURATION\_ERROR if both limits are enabled in the Limit\_Enable property, and the value of the High\_Limit property is less than the value of the Low\_Limit property.*

[Change **Clause 12.2.9**, Analog Input object type, p. 168;  
Change **Clause 12.4.8**, Analog Value object type, p. 181;  
Change **Clause 12.39.8**, Large Analog Value object type, p. 430;  
Change **Clause 12.43.8**, Integer Value object type, p. 453;  
Change **Clause 12.44.8**, Positive Integer Value object type, p. 460;  
Change **Clause 12.61.9**, Accumulator object type, p. 603]

## **12.?.? Reliability**

...

*The Reliability property shall take on a value of CONFIGURATION\_ERROR under these conditions:*

- *If both limits are enabled in the Limit\_Enable property, and the value of the High\_Limit property is less than the value of the Low\_Limit property, or*
- *if the value of Fault\_High\_Limit property is less than the value of the Fault\_Low\_Limit property.*

[Change **Clause 12.17.8**, Loop object type, p. 263]

## **12.17.8 Reliability**

...

*The Reliability property shall take on a value of CONFIGURATION\_ERROR under these conditions:*

- *If the value of the Error\_Limit property is less than zero, or*
- *if the value of the Low\_Diff\_Limit property is less than zero.*

[Change **Clause 12.15.10**, Life Safety Point object type, p. 247]

## **12.15.10 Reliability**

...

*The Reliability property shall take on a value of CONFIGURATION\_ERROR if a particular value is found in more than one of the Fault\_Values property, the Alarm\_Values property or the Life\_Safety\_Alarm\_Values property.*

[Change **Clause 12.16.10**, Life Safety Zone object type, p. 254]

**12.16.10 Reliability**

...

*The Reliability property shall take on a value of CONFIGURATION\_ERROR if a particular value is found in more than one of the Fault\_Values property, the Alarm\_Values property or the Life\_Safety\_Alarm\_Values property.*

[Add a new entry to **History of Revisions**, p. 1364]

**(This History of Revisions is not part of this standard. It is merely informative and does not contain requirements necessary for conformance to the standard.)**

**HISTORY OF REVISIONS**

...	...	...
1	28	<b>Addendum co to ANSI/ASHRAE Standard 135-2020</b> Approved by ASHRAE on September 30, 2024; and by the American National Standards Institute on September 30, 2024.  <ol style="list-style-type: none"><li>1. Clarify Reliability-Evaluation</li><li>2. Event and Fault Parameter Consistency</li></ol>



## **POLICY STATEMENT DEFINING ASHRAE'S CONCERN FOR THE ENVIRONMENTAL IMPACT OF ITS ACTIVITIES**

ASHRAE is concerned with the impact of its members' activities on both the indoor and outdoor environment. ASHRAE's members will strive to minimize any possible deleterious effect on the indoor and outdoor environment of the systems and components in their responsibility while maximizing the beneficial effects these systems provide, consistent with accepted Standards and the practical state of the art.

ASHRAE's short-range goal is to ensure that the systems and components within its scope do not impact the indoor and outdoor environment to a greater extent than specified by the Standards and Guidelines as established by itself and other responsible bodies.

As an ongoing goal, ASHRAE will, through its Standards Committee and extensive Technical Committee structure, continue to generate up-to-date Standards and Guidelines where appropriate and adopt, recommend, and promote those new and revised Standards developed by other responsible organizations.

Through its *Handbook*, appropriate chapters will contain up-to-date Standards and design considerations as the material is systematically revised.

ASHRAE will take the lead with respect to dissemination of environmental information of its primary interest and will seek out and disseminate information from other responsible organizations that is pertinent, as guides to updating Standards and Guidelines.

The effects of the design and selection of equipment and systems will be considered within the scope of the system's intended use and expected misuse. The disposal of hazardous materials, if any, will also be considered.

ASHRAE's primary concern for environmental impact will be at the site where equipment within ASHRAE's scope operates. However, energy source selection and the possible environmental impact due to the energy source and energy transportation will be considered where possible. Recommendations concerning energy source selection should be made by its members.

**ASHRAE · 180 Technology Parkway · Peachtree Corners, GA 30092 · [www.ashrae.org](http://www.ashrae.org)**

### **About ASHRAE**

Founded in 1894, ASHRAE is a global professional society committed to serve humanity by advancing the arts and sciences of heating, ventilation, air conditioning, refrigeration, and their allied fields.

As an industry leader in research, standards writing, publishing, certification, and continuing education, ASHRAE and its members are dedicated to promoting a healthy and sustainable built environment for all, through strategic partnerships with organizations in the HVAC&R community and across related industries.

To stay current with this and other ASHRAE Standards and Guidelines, visit [www.ashrae.org/standards](http://www.ashrae.org/standards), and connect on LinkedIn, Facebook, Twitter, and YouTube.

### **Visit the ASHRAE Bookstore**

ASHRAE offers its Standards and Guidelines in print, as immediately downloadable PDFs, and via ASHRAE Digital Collections, which provides online access with automatic updates as well as historical versions of publications. Selected Standards and Guidelines are also offered in redline versions that indicate the changes made between the active Standard or Guideline and its previous version. For more information, visit the Standards and Guidelines section of the ASHRAE Bookstore at [www.ashrae.org/bookstore](http://www.ashrae.org/bookstore).

### **IMPORTANT NOTICES ABOUT THIS STANDARD**

**To ensure that you have all of the approved addenda, errata, and interpretations for this Standard, visit [www.ashrae.org/standards](http://www.ashrae.org/standards) to download them free of charge.**

**Addenda, errata, and interpretations for ASHRAE Standards and Guidelines are no longer distributed with copies of the Standards and Guidelines. ASHRAE provides these addenda, errata, and interpretations only in electronic form to promote more sustainable use of resources.**